Health and Safety

The use of any electrical appliance requires the following common sense safety rules.

Primarily there is danger of injury or death and secondly the danger of damage to the appliance. These are indicated in the text by the following two conventions:

WARNING: Danger to the person!

IMPORTANT: Damage to the appliance!

In addition, we offer the following safety advice.

Location

- This appliance is intended to be used in household and similar applications such as:

  farm houses;

  by clients in hotels, motels and other residential type environments;

  bed and breakfast type environments.

  It is not suitable for use in staff kitchen areas in shops, offices and other working environments.
- Always locate your appliance away from the edge of the worktop.
- Do not place the bowl used with the appliance on a highly polished wooden surface as damage may occur to the surface.
- Do not place the appliance on or near a hot surface, such as a hot plate or radiant rings or near a naked flame.

Mains cable

- Do not let the mains cable hang over the edge of the worktop where a child could reach it.
- Do not let the lead run across an open space e.g. between a low socket and a table.
- Do not let the cable run across a cooker or other hot area which might damage the cable.
- The mains cable should reach from the socket to the base unit without straining the connections.
- The power cord cannot be replaced. Contact Morphy Richards for advice.

Personal safety

- Avoid touching moving parts. Keep hands, hair and clothing, and utensils away from the hand mixer attachment blades during operation, to prevent personal injury and/or damage to the appliance.
- WARNING: To protect against the risk of electric shock, NEVER immerse the appliance body in water or in any other liquid and always ensure the electrical connections are kept dry.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

Children

- Children do not understand the dangers associated with operating electrical appliances. Never allow children to use this appliance.
- Children should be supervised to ensure that they do not play with the appliance.
- Teach children to be aware of dangers in the kitchen, warn them of the dangers of reaching up to areas where they cannot see properly or should not be reaching.

Other safety considerations

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of attachments or tools not recommended or sold by Morphy Richards may cause fire, electric shock or injury.
- Do not use the appliance for anything other than it's intended purpose.
- Unplug from the outlet when not in use, or when left unattended, and before assembling, disassembling or cleaning.

Product specific safety

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of attachments or tools not recommended or sold by Morphy Richards may cause fire, electric shock or injury.
- Do not use the appliance for anything other than it's intended purpose.
- Unplug from the outlet when not in use, or when left unattended, and before assembling, disassembling or cleaning.

Electrical requirements

Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be A.C. (Alternating Current).

If the socket outlets in your home are not suitable for the plug supplied with this appliance, the plug should be re moved and the appropriate one fitted.

WARNING : The plug removed from the mains lead, if severed, must be destroyed, as a plug with a bared flexible cord is hazardous if engaged into a live socket outlet.

Should the fuse in the 13 amp plug require changing, a 13 amp BS1362 fuse must be fitted.

WARNING: This appliance must be earthed.

48989 rev3_Layout 1 02/09/2011 09:47 Page 2

FP48989 MUK Rev 3 09/11

Registering your 5 year guarantee

Your standard one year guarantee is extended for an additional 36 months when you register the product within 28 days of purchase with Morphy Richards. If you do not register the product with Morphy Richards within 28 days, your product is guaranteed for 2 year. To validate your 5 year guarantee register with us online at
www.morphyrichards.co.uk
Or call our customer registration line
UK 0844 871 0962
IRE 1800 409 119

N.B. Each qualifying product needs to be registered with Morphy Richards individually.

Please note that the 5 year guarantee is only available in the UK and Ireland. Please refer to the 2 year guarantee for more information.

Your 2 year guarantee

It is important to retain the retailer's receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.

Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 24 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You may be asked to return a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions), the faulty appliance will then be repaired or replaced as appropriate and dispatched usually within 7 working days of receipt.

If, for any reason, this item is replaced or repaired during the 2 year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

To qualify for the 2 year guarantee, the appliance must have been used according to the instructions supplied. For example, crumb trays should have been emptied regularly.

Exclusions

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturer's recommendations or where the fault has been caused by power surges or damage caused in transit.

2 The appliance has been used on a voltage supply other than that stamped on the products.

3 Repairs have been attempted by persons other than our service staff (or authorised dealer).

4 The appliance has been used for hire purposes or non domestic use.

5 The appliance is second hand.

6 Morphy Richards reserves the right not to carry out any type of servicing under the guarantee at its discretion

7 Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.

8 Batteries and damage from leakage are not covered by the guarantee.

- This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer. Morphy Richards products are intended for household use only. See usage limitations within the location safety instructions.

Disclaimer

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of it's models at any time.

For electrical products sold within the European Community. At the end of the electrical products useful life, it should not be disposed of with household waste.

Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country

IF YOU ARE HAVING A PROBLEM WITH ONE OF OUR PRODUCTS, CALL OUR HELPLINE:

UK: 0844 871 0960
EIRE: 1800 409 119
SPARES: 0844 873 0726

morphy richards

The After Sales Division
Morphy Richards Ltd
Mexborough, South Yorkshire,
England, S64 8AJ

Helplines (office hours)
UK 0844 871 0960
Spare Parts 0844 873 0726
Republic of Ireland 1800 409 119
www.morphyrichards.com

CE

48989 rev3_Layout 1 02/09/2011 09:47 Page 3

FP48989 MUK Rev 3

morphy richards®

up to* 5 year guarantee
*Upon registration with Morphy Richards (UK & ROI only)

Accents Hand Mixer



For competitions, product hints and tips and more join us at
www.homeofthehouseproud.com
www.facebook.com/morphyrichardsuk
www.twitter.com/loveyourmorphy

www.morphyrichards.com

* Register online for your 5 year guarantee. See back of this instruction book for details. (UK and Ireland customers only)

Product overview



Features

(1) Speed Control
(2) Turbo Button
(3) Release Button
(4) Sockets
(5) Beaters
(6) Dough Hooks

Using your Accents Hand Mixer



Ensure the mixer is switched off. Insert the Beaters **(5)** or Dough Hooks **(6)** into the Sockets. See 'Inserting the Dough Hooks; below for more information.



Place the mixer into the bowl. Do not switch the mixer on when it is not placed in a suitable mixing bowl.



Turn the Speed Control **(1)** on to the first speed setting. Increase the speed as required. Turn off before removing from the bowl.



After use, press on the top edge of the Release Button **(3)** to remove the Beaters or Dough Hooks for cleaning.

Before first use

Before using the Accents Hand Mixer for the first time, clean the Beaters **(5)** and Dough Hooks **(6)** in warm soapy water.

Important

Do not operate the Accents Hand Mixer continuously for more than 6 minutes (with the Beaters) or 1 minute (with the Dough Hooks). After using for these lengths of time, let it cool down for 10 minutes before using again.

Turbo Boost

The Accents Mixer has 5 different mixing speeds as well as a Turbo Boost Button **(2)**.

Press the Turbo Boost Button while the mixer is in use for a slight increase in speed.

Inserting the Dough Hooks



When attaching the Dough Hooks **(6)** into the Sockets **(4)**, the Dough Hook with the groove on the shaft should be inserted into the Socket with the sleeve.

Top tips

When making dough, first mix the dry ingredients, oils, fats or butter, with the beater for approximately 30 seconds on speed 5 until they form breadcrumbs. Change to the dough hooks and gradually add the water using speed 5. Change to speed 2 to knead the dough for approximately 1 minute.

Care and cleaning

- Before cleaning, switch the mixer off and unplug from the mains.
- Remove and wash the Beaters and Dough Hooks in warm soapy water and dry well.
- Wipe the mixer with a damp cloth. Do not use any abrasive or solvent-based cleaner.
- The Beaters and Dough Hooks are dishwasher safe (top rack only.)

WARNING: Never immerse the motor unit in water or other liquid.

Contact us

Helpline

If you are having a problem with your appliance, please call our Helpline, as we are more likely to be able to help than the store you purchased the item from.

Please have the product name, model number and serial number to hand when you call to help us deal with your enquiry quicker.

UK Helpline: **0844 871 0960**

IRE Helpline: **1800 409 119**

Spares: **0844 873 0726**

Talk To Us

If you have any questions or comments, or want some great tips or recipe ideas to help you get the most out of your products, join us online:

Blog: **www.homeofthehouseproud.com**

Facebook: **www.facebook.com/morphyrichardsuk**

Twitter: **www.twitter.com/loveyourmorphy**

Website: **www.morphyrichards.com**

Notes